


COUNTER CURRENT SYSTEM, TYPE STP



COUNTER CURRENT SYSTEM, TYPE STP

NR.	DESCRIPTION	PART NR.
1	Motor	
2	Screw	7034155
3	Nut	7034156
4	Washer	7034157
5	Pump Cover	7034158
6	O-ring pump body	7017372
7	Support block	7034159
8	Foot support	7034160
9	O-ring drain plug	7017373
10	Drain plug	7017374
11	Bolt	7034161
12	Washer	7034162
13	O-ring	7034163
14	Inlet pipe	7034164
15	Inlet nut	7034165
16	Pump body	7017375
17	O-ring	7034166
18	Outlet pipe	7034167
19	Outlet nut	7034168
20	Impeller nut	7017376
21	Impeller STP-2200 & STP-2200SS	7017377
21	Impeller STP-2200-T & STP-2200SS	7017378
21	Impeller STP-3000-T & STP3000SS-T	7017379
21	Impeller STP-4000-T & STP-4000SS-T	7017380
22	Mechanical seal	7017381
23	Air regulation	7026755
24	Air regulation hose	7034169
25	Pneumatic hose	7026756
26	Pneumatic button nut and bottom	7017383
27	Front panel STP	7017382
28	Pneumatic button nut and bottom	
29	Screw cover	7034171
30	Rear cover	7034172
31	Air adjuster	7034173
32	Bushing	7034174
33	Water adjuster	7034175
34	Front cover	7034176
35	Screw	7034177
36	Nozzele bas	
37	O- ring	7034178
38	Cable gland (gland seal butt joint)	7026752
39	Screw	7034179
40	Wilde fastening flange	7026753
41	Wilde adhesive seal	7034180
42	Main housing	7034181
43	Valve	7034182
	Control box 4-6,3A for STP2200 T	7017384
	Control box 9-14A for STP2200	7017385
	Control box 6-10A for STP 3000 T	7017386
	Control box 9-14A for STP4000 T	7034396
	Engine black box 230 volt	7017388
	Engine black box 400 volt	7017389