


COUNTER CURRENT SYSTEM, TYPE STP SS



COUNTER CURRENT SYSTEM, TYPE STP SS

NR.	DESCRIPTION	PART NR.
1	Screw cover	7034183
2	Tapping screw	7034184
3	Light cover	7034185
4	Pneumatic button light	7034186
5	Led light	7026711
6	O-ring	7034187
7	O-ring	7034188
8	Pneumatic button pump	7034189
9	Air regulation cover	7034190
10	Air regulation	7034191
11	O-ring	7034192
12	O-ring	7034193
13	Stainless steel panel	7034194
14	Screw	7034195
15	Nozzle housing	7034196
16	Airegulator base	7034197
17	Tapping screw	7034198
18	O-ring	7034199
19	Cable gland M16	7034200
20	Pneumatic hose	7034201
21	Nozzle	7034202
22	Tapping screw	7034203
23	Nozzle base (Air suction unit)	7026755
24	O- ring	7034205
25	Back plate (Pneumatic hose 4mm)	7026756
26	Screw	7034207
27	Support flange	7034208
28	Stainless steel handle	7034209
29	Housing seal	7034210
30	Main housing	7034211
31	Suction valve	7034212
32	Air suction hose	7034213
33	Protective conduit	7034214
34	Ball valve	7034215
35	Motor	
36	Screw	7034155
37	Nut	7034156
38	Washer	7034157
39	Pump Cover	7034158
40	O-ring pump body	7017372
41	Support block	7034159
42	Foot support	7034160
43	O-ring drain plug	7017373
44	Drain plug	7017374
45	Bolt	7034161
46	Washer	7034162
47	O-ring	7034163
48	Inlet pipe	7034164
49	Inlet nut	7034165
50	Pump body	7017375
51	O-ring	7034166
52	Outlet pipe	7034167
53	Outlet nut	7034168
54	Impeller nut	7017376
55	Impeller STP-2200 & STP-2200SS	7017377
55	Impeller STP-2200-T & STP-2200SS	7017378
55	Impeller STP-3000-T & STP3000SS-T	7017379
55	Impeller STP-4000-T & STP-4000SS-T	7017380
56	Mechanical seal	7017381
	Control box 9-14A for STP-SS 2200	7034397
	Control box 4-6,3A for STP-SS 2200 T	7034398
	Control box 6-10A for STP-SS 3000 T	7034399
	Control box 9-14A for STP-SS 4000 T	7034400